





## DRIVE-IN RACKING



The Drive-in system is used to ensure maximum usage of floor area when the warehouse space is minimal. This system is often used in the cold room environment saving energy and warehousing costs.

Stock rotation is on a first in last out basis except when the system is designed as a drive through system where the product can be loaded or picked from both sides.





HEAD OFFICE – Johannesburg: +27 11 824 1527

37 Dekema Road - P O Box 14217

WADEVILLE

1422 – South Africa



**Cape Town:** +27 21 905 0500

**Durban:** +27 31 465 0377

Acrow Italia: +39 0124 418 112

www.acrow.co.za